





1K Series Stainless Steel Submersible Pumps Models 1K100-1K505

FEATURES

- 304SSL construction offers corrosion resistance and increases operating life over typical cast iron models.
- Unique bulge formed components eliminates harsh radius and welds and provides greater efficiency and durability.
- Lubricated double mechanical seal offers dependable performance with a variety of liquids.
- Air filled, continuous-duty motors for reliable, long term operation.
- Single phase motor features permanent split capacitor and thermal protection with automatic reset for added protection and extend motor life.
- Versatile, reliable operation whether fully or partially submerged.
- Multiple sizes from 1/3 to 1-1/2 hp offers application flexibility.
- Sealed float switch for automatic operation.

Quality Materials

- Casing is 304SSL for durability over traditional cast iron.
- Semi-open impeller is 304SSL for long life, durability and economy. (1K100 and 1K102 feature RTP-Noryl.)
- Shaft is 304SSL for dependable, long life.
- Motor frame is 304SSL for dependability.
- Fasteners are all 304SS for durability.
- Shaft Seals are special blend NBR and FPM for compatibility and long life.
- Sealed Bearings for longer life.

SPECIFICATIONS

UUU.						
		U.S. Measure				
Flow Range		up to 88 GPM				
Pressure Range		up to 24 PSI				
		up to 55 Ft. Head				
RPM		3450 RPM				
Discharge Fitting	1/3 HP	1-1/4 NPT				
	1/2-1-1/2 HP	1-1/2 NPT				
Motor Phase	Single	Class F 115V				
	Three	Class F 208/230V				
	Three	Class F 460V				
Cycle		60 Hz				
Cable Length	1 PH[Gauge AW	G 16, UL/CSA 3-Prong] 20 Ft.				
	3 PH[Ga	auge AWG 16, UL/CSA] 20 Ft.				
Float Operation		Manual or Automatic				
Maximum Starts/Hour2						
Maximum Tempera	ture (Continuous)	122°F				
	(Intermitent)	140°F				
Maximum Solids Dia	ameter	3/8"				
Weight (see charts)		11-31 lbs.				
Dimensions (see charts)						
	Length	10.25-17.18"				
	Diameter	6.37-8.25"				

CAPACITY IN GALLONS PER MINUTE (GPM)											
MODEL		FEET OF HEAD									
	5	10	15	20	25	30	35	40	45	50	55
1K100-103	45	39	31	21	5						
1K201-205		73	67	60	51	40	27	9			
1K301-305				74	67	58	49	39	28	16	
1K404-405					82	75	65	55	42	27	
1K504-505					88	81	74	65	54	43	25

GENERAL SAFETY AND OPERATION

- 1. Use with the proper electrical receptacle. On single phase models cord is supplied with a grounding type, 3-prong plug.
 - NOTE: DO NOT USE GROUNDING ADAPTER.
- 2. Do not use if outer covering of cord becomes excessively cut or worn.
- 3. Each pump comes with a built-in handle for lifting. For added convenience, the 899045 25 ft. marine rope can be attached to the handle.


WARNING

Do not lift with power cord. This can cause damage to the connection and result in shock or serious injury.


4. Continued cycling on and off is an indication the motor is in overload. Make certain the pump is level and adequately submersed in liquid.

NOTE: CONTINUED OPERATION WITH EXCESSIVE CYCLING WILL OVERHEAT AND BURN OUT MOTOR.

5. All automatic models come with a float switch to shut -off unit when liquid level drops below safe operation. For field retro-fit, the 899080 [115V] or 899081 [230V] float switch can be added to automate the manual units.



1K SERIES PERFORMANCE RANGES



TROUBLESHOOTING

PUMP WON'T START

- Blown fuse or tripped circuit
 Check power supply.
- Low voltage line
- · Defective motor
- Impeller clogged

- Check power supply.
- Overheated and burned out unit must be replaced. • Check for proper particle size. Maximum 3/8" and 2% concentrate and raise from bottom of pit.
- Reposition pump in liquid with minimum 2-3/8" liquid.

Not primed PUMP CYCLES ON AND OFF

- Insufficient liquid
- Pump run dry
- Liquid temperature to high
- Reposition pump in pit or remove if liquid is too low.
- · Keep liquid within pump limits. Remove if liquid is low.
- . Keep liquid within pump limits.


PUMP OPERATES BUT DELIVERS LITTLE FLOW

- Impeller clogged
- Low voltage

Worn seals

- Check liquid and particle size. Flush impeller area.
- · Check power supply.
- Replace pump unit.

	AUTOMATIC MODELS											
					Pump-Motor Dimensions (in.)							
Model	HP	Phase	Volts	Amps	Α	В	C	D	E (NPT)	Wt. (lbs.		
1K100	1/3	1*	115	4.0	10.25	8.06	6.37	2.26	1.25	11		
1K101	1/3	1*	115	4.0	10.25	8.06	6.37	2.26	1.25	11		
1K201	1/2	1*	115	9.0	17.18	13.62	8.25	2.62	1.50	27		
1K301	3/4	1*	115	12.2	17.18	13.62	8.25	2.62	1.50	27		
	MANUAL MODELS											
Model	HP	Phase	Volts	Amps	A	В	C	D	E (NPT)	Wt. (lbs.		
1K102	1/3	1*	115	4.0	10.25	8.66	6.37	2.37	1.25	11		
1K103	1/3	1*	115	4.0	10.25	8.66	6.37	2.37	1.25	11		
1K203	1/2	1*	115	9.0	17.18	13.62	8.25	2.37	1.50	27		
1K204	1/2	3	208/230	3.0/3.1	13.87	12.37	8.25	2.37	1.50	27		
1K205	1/2	3	460	1.55	13.87	12.37	8.25	2.37	1.50	27		
1K303	3/4	1*	115	12.2	17.18	13.37	8.25	2.37	1.50	28		
1K304	3/4	3	208/230	3.9/3.8	13.87	12.37	8.25	2.37	1.50	28		
1K305	3/4	3	460	2.0	13.87	12.37	8.25	2.37	1.50	28		
1K404	1	3	208/230	4.8/4.8	14.81	13.37	8.25	2.37	1.50	31		
1K405	1	3	460	2.5	14.81	13.37	8.25	2.37	1.50	31		
1K504	1-1/2	3	208/230	5.4/5.3	14.81	13.37	8.25	2.37	1.50	31		
1K505	1-1/2	3	460	2.7	14.81	13.37	8.25	2.37	1.50	31		
-			nly single i									



WARRANTY

This pump is warranted for one year from date of purchase.

Improper installation and use will void the warranty.

Tampering with the power cord, impeller or seals will void the warranty.

World Headquarters CAT PUMPS

1681 - 94th Lane N.E. Minneapolis, MN 55449 - 4324 Phone (763) 780-5440 — FAX (763) 780-2958 e-mail: techsupport@catpumps.com www.catpumps.com

> International Inquiries FAX (763) 785-4329 e-mail: intlsales@catpumps.com

The Pumps with Nine Lives

CAT PUMPS (U.K.) LTD.

1 Fleet Business Park, Sandy Lane, Church Crookham FLEET, Hampshire, GU52 8BF, England Phone Fleet 44 1252-622031 — Fax 44 1252-626655 e-mail: sales@catpumps.co.uk

N.V. CAT PUMPS INTERNATIONAL S.A.

Heiveldekens 6A, B-2550 Kontich, Belgium Phone 32-3-450.71.50 — Fax 32-3-450.71.51 -mail: cpi@catpumps.be www.catpumps

CAT PUMPS DEUTSCHLAND GmbH

Buchwiese 2, D-65510 Idstein, Germany Phone 49 6126-9303 0 — Fax 49 6126-9303 33 e-mail: catpumps@t-online.de www.catpumps.de