









FEATURES

- Glycerine filled for consistent, accurate readings, shock and pulsation protection.
- Hermetically sealed 304 stainless steel case eliminates corrosion risk and liquid or humidity within gauge.
- Built-in snubber to reduce pressure fluctuations.
- Install on pump discharge manifold to allow accurate monitoring of pump performance and enhance system safety.

Pressure Gauges 6086 Models 6088 6089

SPECIFICATIONS

		U.S. Measure	Metric Measure
MODEL 60	86		
Pressure Range		.0-1500 PSI	(0-105 BAR)
Temperature Range		68-160°F	(20-71°C)
Fitting [Bottom Mount]		1/4" NPTM	(1/4" NPTM)
Accuracy [FSD]		±1-3%	(±1-3%)
Weight		6.9 oz.	(0.19 kg)
Dimensions	Diameter	2.64"	(67.1 mm)
	Depth	1.12"	(28.4 mm)
	Full Height	3.5"	(88.9 mm)
MODEL 60	88		
Pressure Ra	nge	.0-3000 PSI	(0-210 BAR)
Temperature Range		68-160°F	(20-71°C)
Fitting [Bottom Mount]		1/4" NPTM	(1/4" NPTM)
Accuracy [FSD]		±1-3%	(±1-3%)
Weight		6.9 oz.	(0.19 kg)
Dimensions	Diameter	2.64"	(67.1 mm)
	Depth	1.12"	(28.4 mm)
	Full Height	3.5"	(88.9 mm)
MODEL 60	89		
Pressure Ra	nge	0-6000 PSI	(0-415 BAR)
Temperature Range		68-160°F	(20-71°C)
Fitting [Bottom Mount]		1/4" NPTM	(1/4" NPTM)
Accuracy [FSD]		±1-3%	(±1-3%)
Weight		6.9 oz.	(0.19 kg)
Dimensions	Diameter	2.64"	(67.1 mm)
	Depth	1.12"	(28.4 mm)
	Full Height	3.5"	(88.9 mm)

SELECTION: Select a pressure gauge with a rating that exceeds the system operating pressure by at least 25%. This gauge is designed for the discharge line (high pressure side of system).

INSTALLATION: These pressure gauges are designed to monitor high pressure typically read at the pump or downstream to verify the performance of other components. To assure the operating pressure does not exceed the rated pump pressure. mount the pressure gauge at the pump discharge manifold. Always read your system pressure at the pump or between the pump and regulating device. Excessive pressure spikes may occur while the unit is in by-pass and could result in damage to the pump or void the warranty.

OPERATION: Best performance will be received from the gauge if used with system pressures up to 75% of maximum gauge rating. The pressure gauge automatically reads the system pressure during operation and will register pressure spikes, fluctuations and low pressure. Sudden changes or fluctuations in set system pressure or continued low pressure readings are the first signs that system maintenance is necessary.

MAINTENANCE: The pressure gauge is airtight and trouble free. Avoid overpressure, overheating, freezing or harsh chemicals to receive optimum life from your gauge. Replace when damaged.

TROUBLESHOOTING

- Fluctuating pressure Lack of liquid to pump.
 - Foreign object in valves of pump.
 - Worn seals or o-rings in pump or accessories.
 - Air leak in system.

Low pressure with gun open

- Lack of liquid to pump.
- Worn seals in pump.
- Worn valves in pump.
- Gauge's rubber orifice plugged.

Pressure spikes

 Unloader or Regulator malfunction or improper adjustment.

WARRANTY

90 Day Warranty

Refer to complete CAT PUMPS Warranty for further information.

World Headquarters CAT PUMPS

1681 - 94th Lane N.E. Minneapolis, MN 55449 - 4324 Phone (763) 780-5440 — FAX (763) 780-2958 e-mail: techsupport@catpumps.com www.catpumps.com

> International Inquiries FAX (763) 785-4329 e-mail: intlsales@catpumps.com



CAT PUMPS (U.K.) LTD.

1 Fleet Business Park, Sandy Lane, Church Crookham FLEET, Hampshire, GU52 8BF, England Phone Fleet 44 1252-622031 — Fax 44 1252-626655 e-mail: sales@catpumps.co.uk

N.V. CAT PUMPS INTERNATIONAL S.A.

Heiveldekens 6A, B-2550 Kontich, Belgium Phone 32-3-450.71.50 — Fax 32-3-450.71.51 e-mail: cpi@catpumps.be www.catpumps

CAT PUMPS DEUTSCHLAND GmbH

Buchwiese 2, D-65510 Idstein, Germany Phone 49 6126-9303 0 — Fax 49 6126-9303 33 e-mail: catpumps@t-online.de www.catpumps.de